

### Components



x1 Top Bowl with Connecting Rod (Supplied)



x1 Bottom Bowl on a Post Top Adapter (Not Supplied)



x1 3/16" Allen Key (Not Supplied)

**STEP 1**

Disassemble the Bottom Bowl & Adapter using the Allen Key to unscrew the bolt securing the Bowl to the Adapter. You may discard the bolt.

**STEP 2**

Remove the bolt from the bottom of the Connecting Rod.

**NOTE**

DO NOT DISCARD THE BOLT AND WASHERS.

**STEP 4**

Place the Top Bowl upside down on a flat surface and lower the Bottom Bowl onto the upturned Connecting Rod so that the exposed thread of the Bolt fits into the Connecting Rod. Tighten the Bolt using the Allen Key.

**HINT**

Make sure the bolt is fully tightened.

**COMPLETED PRODUCT**

**STEP 3**

Take the Bolt from the Connecting Rod (with its washers in place) and pass it upwards through the hole in the Adapter and the Bottom Bowl

**HINT**

You may find it easier to do this with the Bottom Bowl and Adapter upside down

